

HANDLE BOLTS

Fits MOST WALK-BEHIND LAWNMOWERS

CAUTION:

Disconnect spark plug wire before working on mower.

How to install :

1. Remove one side at a time.
2. Insert bolt through upper handle, then through lower handle.
3. Insert bolt into knob and screw in finger tight.
4. Make sure throttle control cable is under lower handle crossbar.
5. Reconnect spark plug wire.

